# Calisto 5300 Speakerphone


User Guide

### **Contents**

```
Controls and status lights 3
  USB Bluetooth adapter (adapter model only) 3
Setup 5
  Mobile setup 5
  Corded setup 5
  USB adapter setup (BT600 models only) 5
  Load software 6
Charge 7
  Check battery status 7
  Charge 7
Daily Use 8
  Power 8
  Answer or End a call 8
  Place a call on hold 8
  Mute/Unmute 8
  Volume 8
  Microsoft Teams button (Teams models only) 8
Support 9
```


## Controls and status lights

A corded, portable speakerphone with mobile connectivity.



<b>4</b> ) ±	Volume
\$	Mute
<del>-</del> >o<-	LED
ūji	Press to interact with Microsoft Teams (app required)
•	Call button
<u> </u>	Kensington lock port
(h	Power
*	Bluetooth switch (speakerphone)
*	Bluetooth button (BT600 adapter)

USB Bluetooth adapter (adapter model only)



**NOTE** Adapter design may vary

#### Standard LEDs

USB LEDs	What they mean
Flashing red and blue	Pairing
Solid blue	Headset connected
Flashing blue	On a call
Solid red	Mute active
Flashing purple	Streaming media from computer

#### LEDs when Microsoft Teams\* is detected

USB LEDs	What they mean
Flashing red and blue	Pairing


USB LEDs	What they mean
Solid purple	Headset connected
Flashing blue	On a call
Solid red	Mute active
Pulsing purple	Microsoft Teams notification

**NOTE** \*Requires Microsoft Teams application

### Setup

#### Mobile setup

1 To pair your mobile device with your speakerphone, slide the Power switch towards the Bluetooth icon to the right for 2 seconds. You hear "pairing" and the LED next to the Bluetooth icon flashes red and blue.



- 2 Activate Bluetooth on your phone and set it to search new devices, select Poly CL5300 Series.
- 3 Pairing is successful when you hear "pairing successful" and the LED goes out.

#### Corded setup


Connect the USB cable from the USB port on the speakerphone to the USB port on your computer.



### USB adapter setup (BT600 models only)

Your Bluetooth USB adapter comes pre-paired to your speakerphone.

1 Turn on your speakerphone and insert the Bluetooth USB adapter into your computer.




Pairing is successful when you hear "pairing successful" and the USB adapter turns solid blue.
NOTE Adapter design may vary.

#### Pair USB adapter again

Your USB adapter is pre-paired to your speakerphone. In the event that your adapter is disconnected or bought separately, manually pair the adapter to your headset.

- 1 Insert the Bluetooth USB adapter into your laptop or computer and wait for your computer to recognize it.
- Put your speakerphone in pair mode by sliding the Power switch towards the Bluetooth icon to the right for 2 seconds. You hear "pairing" and the LED next to the Bluetooth icon flashes red and blue.
- Put your adapter into pair mode by pressing and holding the recessed pair button with a pen or paperclip until the adapter flashes red and blue.



**NOTE** Adapter design may vary

Pairing is successful when you hear "pairing successful; PC connected" and the adapter LED turns solid blue.

#### Load software

Download Plantronics Hub for Windows/Mac by visiting poly.com/software. This allows you to customize your device behavior through advanced settings and options.

## Charge


#### Check battery status

To check the battery status of your speakerphone, slide the power button to the right and release.



#### Charge

Charge the speakerphone via USB using your computer or a USB AC adapter (not provided). The Power switch LED flashes while charging and turns off when fully charged. Allow 3.5 hours for a full charge.



### Daily Use


Power

Slide the Power button to the right to power on. The speakerphone LED illuminates white and you hear "power on."




Answer or End a call

A short press of the Call button answers or ends a call.



Place a call on hold

To place a call on hold, press the Call button for 2 seconds.



Mute/Unmute

A short press of the Mute button mutes or unmutes the microphones.

Volume

Press the up (+) or down (-) volume buttons for the desired volume.

Microsoft Teams button (Teams models only)

Press the Teams button to interact with Microsoft Teams when not on a call. **NOTE** The Microsoft Teams app must be installed.

## Support

#### **NEED MORE HELP?**

#### poly.com/support

Plantronics, Inc.	Plantronics B.V.
345 Encinal Street	Scorpius 171
Santa Cruz, CA 95060	2132 LR Hoofddorp
United States	Netherlands

<sup>© 2020</sup> Plantronics, Inc. All rights reserved. Poly, the propeller design, and the Poly logo are trademarks of Plantronics, Inc. Bluetooth is a registered trademark of Bluetooth SIG, Inc. and any use by Plantronics, Inc. is under license. All other trademarks are the property of their respective owners. Manufactured by Plantronics, Inc.

216075-06 09.20

